

# Adapter API RP 1400


Mod. 1527 & 1527L



Mod. 1527



#### **(€** 477 ⟨Ex⟩ ||36





### **APPLICATION**

It's a Safety accessory in according with Directives ATEX 2014/34/EU and PED 2014/68/UE. The adapter API RP 1004 is used to prevent any possible leaking during the process of transferring fluids during the loading/discharge of tank trucks.

There are two versions of the adapter, with and without a lever for manual opening.

DIMENSIONS			
Code	DN1	DN2	Α
1527-00	API RP 1004	4" TTMA	174
1527L-00	API RP 1004	4" TTMA	174





PARTS	1527	1527 L
BODY	ALUMINIUM	ALUMINIUM
INTERNAL COMPONENT	STAINLESS STEEL	STAINLESS STEEL
FLANGE	4" TTMA	4" TTMA
GASKET	VITON®	VITON®
MAX WORKING TEMPERATURE	- 20°C + 60°C	- 20°C + 60°C
MAX WORKING PRESSURE	5 bar	5 bar
MAX FLOW RATE	2500 L/MIN	2500 L/MIN

Mod. 1527 L

# **CHEMICAL SUITABILITY**

- Standard Model is for traditional fuel without additivies or compatible chemical products

## INSTALLATION

- The adapter API RP 1004 can be installed on every section of the tank truck according to the number of products
- For correct installation follow the Directives and product User Manual.
- For custom application or maintenance write to: <u>quality@ridart.it</u>.
- Declaration of Conformity and User Manual are available on:

#### www.ridart.it/support

## MAINTENANCE

- Periodically check the device is necessary to remove possible dirty.
- Always replace the product after fire or deflagration.
- In case of tampering warranty expires and safety protection is not quaranteed.

